



## Connect HIGOAL panel to shadow curtain

Shadow curtain (inside a window) voltage is 24VDC.  
 Connection will be with special controller supplied by shadow curtain supplier.

Shadow curtain workflow:  
 When controller input is + in A, - in B = curtain opens  
 When controller input is - in A, + in B = curtain closes  
 No voltage to controller = curtain stops.

Connecting to the HIGOAL panel:  
 Set appropriate channels to motor mode.  
 Connect to each output HIGOAL Nc/No relay.

HIGOAL Nc/No connection:  
 L (Brown) - Open output in HIGOAL panel  
 N (Blue) - Zero line  
 Com (Black) - connects to Com in curtain's controller  
 No (Red) - connects to open channel in curtain's controller  
 Nc (Yellow) - not used.

