


Connect Stairs Switch to panel

The guide suitable to all panels.

Stairs light is using building electricity.

Connecting will be made by HIGOAL NO/NC



1. Set using dipswitch the desired output to momentary.
 2. Connect NO/NC's L wire to the momentary output.
 3. Connect NO/NC's N wire to panel's N.
 4. Connect Red and Black wires from NO/NC to stairs light.
- Note: Should be installed by a certified professional.